

































1 Start setup mode











- Put on the headset.
- Simultaneously press and hold both headset volume buttons until the voice prompt says "Setup" and then release the buttons.



2 Setup mode


- The headset buttons are used to cycle through the settings and values.
- The base lights , or voice prompts are used to indicate which setting and value is currently selected.

Settings			Values		
Cycle through settings			Cycle through values		
Base light	Voice prompt	Setting	Base light	Voice prompt	Value
 flash x1		Mute reminder tone			On (default)
					Off
 flash x2		Ringtone			Ringtone 1 (default)
					Ringtone 2
					Ringtone 3
					Ringtone 4
					Ringtone 5
 flash x3		Audio protection			Peakstop (default)
					Peakstop and Intellitone
 flash x4		Wireless range			Normal range (default)
					Low range
					Very low range
 flash x5		Auto sleep mode			Off (default)
					On

 flash x6	▶	Remote call control (some phones may not be auto-detected, and will need to be manually configured)		▶	Auto-detect (Default)
				▶	GN1000/RHL/none
				▶	Jabra IQ
				▶	DHSG
				▶	MSH
				▶	Optipoint
 flash x7	▶	Wideband audio		▶	Off (default)
				▶	On

3 End setup mode

When finished, simultaneously press and hold both headset volume buttons until the voice prompt says "Goodbye" and then release the buttons.

The base will restart and update the settings, indicated by the white battery icon  on the base.

